



ISO 9001 CERTIFIED

## BAR'S LEAKS TECHNICAL BULLETIN

Tech Bulletin #: TB-HJ12-2

Page 1 of 1

Date 1<sup>st</sup> Issued: May 31, 2006

Date Revised: June 11, 2018

Bar's Leaks Jack Oil With Stop Leak

Part #: HJ12

# JACK OIL WITH STOP LEAK

Bar's Leaks<sup>®</sup> Jack Oil with Stop Leak is specially designed to stop seal and o-ring leaks caused by normal jack wear and age. If you are having to add oil to your jack, it has a leak. Easy fill cap is great for topping fluid off.

Brings life back to old jacks and prevents leaks & seepage on newer jacks. Premium formulation reconditions seals to stop current and future leaks.

- Mixes All Approved Hydraulic Jack Oils
- Non-Corrosive, Non-Clogging & Non-Foaming
- Works in All Floor and Bottle Jacks
- Also Works With All Snow Plow Fluids



## INSTRUCTIONS

Clean area around filler cap. Fill jack to proper level. Do not overfill. Cycle jack by lifting and releasing a few times to release any air caught in system. Leaks usually stop in a few days of normal use. If leak continues, a second application may be required or mechanical attention is needed.

## DOSAGE

One bottle treats 2 to 3 quarts of oil. For larger systems use one bottle for every 2 quarts of oil capacity.

Part Number:	HJ12
UPC Item:	0 46087 00044 1
UPC Case:	1 00 46087 00044 8
Bottle Size:	12 fl. oz. (355 ml)
Bottle Dimensions:	3.4 x 3.6 x 6.6
Bottle Cube:	81
Case Pack:	6 bottles
Case Size:	7.1 x 5.9 x 9.7
Case Cube:	406
Case Weight:	4.92 pounds
Pallet:	TI 35 HI 6 Total 210
Pallet Height:	63 inches