



Tech Bulletin #: TB-HJ12	Part Number: HJ12
Date Issued: January 17, 2020	Date Revised: January 11, 2022
Bar's Leaks® Jack Oil with Stop Leak	Size: 12.5 FL OZ (370 mL)

Jack Oil with Stop Leak

Bar's Leaks® Hydraulic Jack Oil with Stop Leak is specially designed to stop seal and o-ring leaks caused by normal jack wear and age. If you are having to add oil to your jack, it has a leak. Easy fill cap is great for topping fluid off.

Brings life back to old jacks and prevents leaks & seepage on newer jacks. Premium formulation reconditions seals to stop current and prevent future leaks.

WORKS ON ALL:

- Bottle Jacks**
- Floor Jacks**
- Lifts & Rams**
- Shocks**
- Snow Plows**

America's Most Trusted Stop Leak Brand Since 1947

Mixes All Approved Hydraulic Jack Oils

Safe and Easy to Use

Contains Anti-Wear & Oil Stabilizer

Non-Corrosive, Non-Clogging & Non-Foaming

DIRECTIONS:

Clean area around filler cap. Fill jack to proper level. Do not overfill. Cycle jack by lifting and releasing a few times to release any air caught in system. Leaks usually stop in a few days of normal use. If leak continues, repair may be required.

DOSAGE:

One bottle treats 2 to 3 quarts of oil. For larger systems use one bottle for every 2 quarts of oil capacity.

CAUTION:

Do not use in hydraulic brake systems.



Small Oil Leaks – Need to Add Oil 1 X per Month	✓
Medium Oil Leaks – Need to Add Oil 1 X per Week	✓
Extends System Life	✓
Preventative Maintenance	✓
Reduces Wear	✓
Inhibits Foam	✓
Corrosion Protection	✓
Floor & Bottle Jacks	✓