

BAR'S LEAKS® TECHNICAL BULLETIN



Tech Bulletin #: TB-HJ12	Part Number: HJ12
Date Issued: January 17, 2020	Date Revised: n/a
Bar's Leaks® Jack Oil with Stop Leak	Size: 12.5 FL OZ (370 mL)

Jack Oil with Stop Leak

Bar's Leaks® Jack Oil with Stop Leak is specially designed to stop seal and o-ring leaks caused by normal jack wear and age. If you are having to add oil to your jack, it has a leak. Easy fill cap is great for topping fluid off.

Brings life back to old jacks and prevents leaks & seepage on newer jacks. Premium formulation reconditions seals to stop current and prevent future leaks.

America's Most Trusted Stop Leak Brand Since 1947

Mixes All Approved Hydraulic Jack Oils

Safe and Easy to Use

Contains Anti-Wear & Oil Stabilizer

Non-Corrosive, Non-Clogging & Non-Foaming

Works in All Floor and Bottle Jacks

Also Works With All Snow Plow Fluids

INSTRUCTIONS:

Clean area around filler cap. Fill jack to proper level. Do not overfill. Cycle jack by lifting and releasing a few times to release any air caught in system. Leaks usually stop in a few days of normal use. If leak continues, repair may be required.

DOSAGE:

One bottle treats 2 to 3 quarts of oil. For larger systems use one bottle for every 2 quarts of oil capacity.

CAUTION:

Do not use in hydraulic brake systems.



What is Your Jack Problem?

Product Selector HJ12

Jack Won't Lift	✓
Dry & Worn Seals	✓
Floor or Bottle Jack Leaks	✓

Jack Oil With Stop Leak
Will Fix These Problems