



Tech Bulletin #: TB-1196	Part Number: 1196
Date Issued: January 3, 2020	Date Revised: n/a
Bar's Leaks® Radiator Stop Leak	Size: 11 FL OZ (325 mL)

## Radiator Stop Leak

Bar's Leaks® Radiator Stop Leak Sealer is specially designed to stop minor cooling system leaks and drips caused by normal cooling system wear and age.

**Works with ALL Types and Colors of Antifreeze Coolant and / or Water**

**Stops & Seals Coolant Leaks**

**Seals Leaks in Radiators, Gaskets, Heater Cores & Freeze Plugs**

**DANGER:** Opening the cooling system while the engine is hot or running may cause severe burns.

Protect From Freezing

### INSTRUCTIONS:

Cooling systems that are dirty or partially clogged should be flushed before usage. Shake well. Pour Stop Leak into a cool radiator. If direct access to radiator is not available, install in overflow / reservoir tank. One bottle treats 4 gallons. Use 1/2 bottle for four cylinder engines. Fill radiator and overflow tank to proper level and reinstall cap. Drive / idle engine for 15 to 30 minutes. If leak continues, a second application may be required, or mechanical attention is needed. Leave Bar's Leaks in the cooling system for continued protection.

### DOSAGE:

Use one bottle for regular size cooling systems; this covers most 6 and 8 cylinder passenger vehicles and light trucks. Use 1/2 bottle for four cylinder engines. One bottle treats up to 4 gallons. For larger systems use one bottle for every 3 gallons of coolant capacity. Small engines or other small systems use 3 to 4 fluid ounces per gallon of fluid capacity.

